IPAL COMPUTER *COLORING BOOK STATIONS*

Thank you for purchasing your IPAL product. You do not need a keyboard or mouse to play with our toys.

The CD-Rom software for IPAL may be found on the underside of the product insert. This software must run in your CD-Rom drive platform while playing the game.

IPAL COMPUTER BOOKS GENERAL REQUIREMENTS

PC Requirements

- USB Port
- Windows 98, 2000 XP ME
- 500 MHZ PC with at least 128M of RAM
- CD-Rom Drive
- Speakers and sound card.
- ***If using a laptop, IMPORTANT: IPAL Computer Books should be run only when the laptop is being run on battery power and not plugged into the wall, as Laptop adaptors may have unstable power while charging and negatively affect performance of the product.***

PLUG IN USB CONNECTOR OF THE IPAL COMPUTER BOOK TO YOUR COMPUTER FIRST.

Installation of CD-ROM Software

- Remove CD-Rom from case (find CD-Rom on the underside of the package insert).
- Insert CD-Rom into your computer's CD-Rom drive.
- Follow prompts from the software on your PC screen.

Warranty Terms

90 days replacement for defective product only. Contact IPAL for terms, conditions and customer card IPAL Computer Books made learning more fun.

IPAL PC Interactive Coloring Books

Combine traditional coloring and finger painting activity books with the fun of adopting new computer skills.

Select a page to color, plug in the IPAL Coloring Book. Choose a page to color by pressing the color button with your finger and fill in the picture on the page as you watch your art come alive on the PC screen.

Change your mind? No problem. Just select a new color by pressing the color button and recolor the area on your page. When the picture is complete, see your art come alive onscreen with playful animation.

12 pages and 8 colors of fun that never ends!

- Insert the USB connector from the book to the PC (usually located on the rear of your computer).
- Insert the CD-Rom that came with your coloring book. If you do not have DirectX8.0 or Quick Time, you will be asked if you want it installed. If you say yes, the proper files will be loaded onto your PC.
- If the software has already been set up to run on your computer, or if you already have the proper software on your machine, the software will automatically begin.
- The IPAL screens begin to play and then you are prompted to pass the calibration button once, count to 3 and let go.
- Now select a page to color by pressing the traffic light on the bottom of the page. The corresponding page will show up on your computer screen.
- Pick a color by pressing the color buttons; they will highlight your computer screen.
- Press any area of the page to apply the color.
- ***Change your mind? Press the area again and the color you selected will be removed*** from the page, or just select a new color and apply over the old one.
- Once all items are colored on a page, it will automatically animate.
- You can see the animation play again (or at any time) by pressing the animate button.

Other great IPAL Computer Books include:

IPAL Interactive Drive Books: Be a Firefighter and Be A Zookeeper.

IPAL Coloring Book Stations: Fun with Numbers and Fun with Letters

IPAL Flash Card Reader: Animals

IPAL Customer Support:
2466 Peck Road
City of Industry, CA 90601
562-692-7188

Made in China
Patented